

## Adjust The Bottom Rail

If the bottom rail is not level, adjust it by lengthening or shortening the lift cords and ladder cords on one side of the rail. Lengthening is the simpler procedure, so whenever possible you should lengthen the cords to perform this adjustment.

---

**IMPORTANT:** It is recommended that only a professional installer perform this adjustment.

---

- Rotate the bottom rail so that the set screws on the rear of the rail are facing you. The set screws hold the bottom rail cord guides in place.
- Use a  $1/16$ " hex wrench to loosen the two set screws on the side you wish to lengthen or shorten.
- To lengthen the lift and ladder cords, first pull the rear two cords together through the hole between the two set screws.
- Lengthen the front two cords the same amount. Use the hex wrench to form a loop by pulling the cords out from the space between the two set screws.
- Then pull these two cords through the hole between the two set screws. After adjusting the front cords the appropriate amount, pull the two cords through the other end of the cord guide to eliminate the loop.
- Tighten the two set screws. Check the adjustment and re-adjust as needed.
- To shorten the cords, the rear seal and end cap must be removed to gain access to the ends of the cords. Pull the ends of the cords to shorten them.

